How to install Converter Fasteners from EZ Slide Cabinet Hardware:

1. Squeeze or widen the back of the Fastener to fit the width of the cabinet door or drawer. (Fastener is designed to flex to widths of 3/8 to ¾ inch) Place back of Fastener onto back of door or drawer and gently slide on. If handle is loose, gently remove and squeeze until the Fastener fits snug.

2. Screw favorite knob onto the screw stud already embedded in the front of the Fastener. (Knob sold separately)

View installation video: www.YouTube.com/EZSlide1

EZ Slide Cabinet Hardware - No Drilling - Made with recycled aluminum

Like us on Facebook @ EZ Slide Cabinet Hardware

Follow us on Twitter @ EZ Slide Hardware

Thank you!